

GENERATOR SUPPORT




Fig. 47

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
GENERATOR SUPPORT				
1	J-810613	Bracket, generator brace, ass'y	1	1
2	J-GM-120393	Washer, plain	1	1
3	J-GM-120214	Washer, spring	1	1
4	J-GM-120368	Nut, hex.	1	1
5	J-808733	Bracket, generator	1	
	JM60721	Brace		1
6	J-GM-120369	Nut, hex.	3	3
7	J-GM-120382	Washer, spring	6	6
8	J-808961	Spacer		1
9	J-GM-120388	Washer, plain	1	1
10	J-GM-121615	Bolt, hex. hd.	1	1
11	J-GM-120371	Nut, hex.	2	2
12	J-GM-120384	Washer, spring	2	2
13	J-808963	Insulator, engine support front	2	2
14	J-GM-120213	Bolt, hex. hd.	3	3
15	J-GM-120393	Washer, plain		2
16	J-GM-120368	Nut, hex.	4	4
	J-GM-138485	Washer, external tooth	4	4
17	J-808618	Generator ass'y	1	
	JM60939	Generator ass'y		1
18	J-808959-1	Washer, generator insulator bolt	2	2
19	J-808961	Spacer, generator support	1	
	JM60725	Spacer, generator support.....		1
20	J-GM-120390	Washer, plain	4	3
21	JM60724	Washer, plain		1
22	J-A-1395	Insulator, support, generator	2	2
23	J-808958	Bolt, generator support insulator front	1	
	JM60722-1	Bolt, generator support insulator front		1
24	J-808957	Bolt, generator support insulator rear.....	1	
	JM60723	Bolt, generator support insulator rear		1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

GENERATOR SUPPORT (Continued)

25	J-808735	Support, generator, ass'y	1	
	JM60721	Support, generator, ass'y		1
26	JM60439	Support, starter	1	1
27	J-GM-446363	Washer, plain	1	1
28	J-GM-120741	Bolt, hex. hd.	1	1
	J-GM-120214	Washer, spring	1	1
29	J-GM-122138	Bolt, hex. hd.	2	2
30	J-808960	Washer, special	1	1
31	J-GM-178551	Washer, internal and external tooth	1	1
32	JM60487	Strap, engine ground	1	1
33	J-633949	Bolt, hex. hd.	1	1
34	J-GM-120394	Washer, plain	1	1
35	J-GM-121661	Bolt, hex. hd.	1	1
36	JM00250	Cable, bond, engine front support	1	
	JM60694	Cable, bond, engine front support		1
37	JM00809	Bond strap	1	1

DISTRIBUTOR




Fig. 48

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
DISTRIBUTOR				
1	J-808365-T J-117453 JM60443	Distributor, ignition, ass'y Cap, distributor	1	1
2	J-117453	Spring, contact plunger	1	1
3	J-A-1656	Contact, plunger	1	1
4	J-A-1658	Rotor, distributor	1	1
5	J-A-1687	Contact set	1	1
6	J-GM-131954	Screw, locking	1	1
7	J-A-10294	Lockwasher, spring	1	1
8	J-A-1633	Screw, clip breaker arm spring	1	1
9	J-A-1613	Lockwasher, spring	2	2
10	J-A-1667	Washer, plain	1	1
11	J-A-1671	Wick, felt	1	1
12	J-A-1653	Snap ring, cam retaining	1	1
13	J-A-9308	Cam and stop plate	1	1
14	J-A-1684	Spring, antirattle	1	1
15	J-A-1672	Spacer, cam	1	1
16	J-A-9314	Weight, governor	2	2
17	J-120232	Spring set, governor weight	1	1
18	J-A-9312	Shaft, drive	1	1
19	JM61903	Terminal, distributor, ass'y	1	1
20	J-120227	Bracket, cap spring	2	2
21	J-120229	Spring, clamp cap	2	2
22	J-117462	Oiler, press in	1	1
23	J-GM-120392	Washer, plain	2	2
24	J-GM-120854	Bolt, hex. hd.	1	1
	J-GM-120380	Lockwasher, spring	1	1
25	J-637615	Spring, friction	1	1
26	J-A-1685	Rivet, collar	1	1
27	J-A-1659	Collar, drive shaft	1	1
28	J-106740	Washer, thrust drive shaft lower	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
DISTRIBUTOR (Continued)				
29	JM62061	Arm, advance	1	1
30	J-A-1681	Bearing, absorbent	2	2
31	J-GM-121867	Bolt, hex. hd.	1	1
	J-GM-120380	Lockwasher, spring	1	1
32	J-119842	Seal, O ring, distributor	1	1
33	JM62060	Base, distributor	1	1
34	J-A-1673	Washer, thrust, drive shaft upper	1	1
35	J-120226	Bracket, mounting breaker plate	2	2
36	J-120231	Rivet	4	4
37	J-A-9309	Plate, breaker	1	1
38	J-A-1663	Clip, breaker arm spring	1	1
39	J-A-1631	Condenser	1	1
40	J-GM-131880	Screw	1	1
41	J-A-1614	Lockwasher, spring	2	2
42	J-GM-132100	Screw	2	2
	JM60982	Kit, repair, distributor	1	1
		Consists of:		
	J-A-1681	2. Bearing, absorbent		
	J-A-9315	1. Screw, rd. hd.		
	J-GM-131954	1. Screw		
	J-A-1663	1. Calmp, spring		
	J-A-10276	1. Connector, terminal stud		
	J-A-10278	1. Insulator, bushing type		
	J-A-10277	1. Insulation, terminal stud		
	J-A-10280	1. Insulator, washer type		
	J-GM-120614	1. Nut		
	J-A-1685	1. Rivet, collar		
	J-A-120230	1. Stud, terminal		
	J-A-1653	1. Snap ring, cam retaining		
	J-A-1633	1. Screw		

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

DISTRIBUTOR (Continued)

J-GM-132100	2.	Screw
J-A-1672	1.	Spacer, cam
J-A-1614	2.	Lockwasher
J-A-1613	2.	Lockwasher
J-A-1667	1.	Washer, plain
J-A-1673	1.	Washer, thrust
J-106740	1.	Washer, thrust
J-A-1671	1.	Wick, felt
J-A-1687	1.	Contact set
J-A-1658	1.	Rotor
J-A-1631	1.	Condensor

SPARK PLUG AND WIRING




Fig. 49

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

SPARK PLUG AND WIRING

1	JM60066-1	Plug and gasket, spark	4	
	JM60878	Plug and gasket, spark		4
2	JM60400	Cable ass'y, spark plug No.1	1	1
3	JM60402	Cable ass'y, spark plug No.2	1	1
4	JM60404	Cable ass'y, spark plug No.3	1	1
5	JM60406	Cable ass'y, spark plug No.4	1	1
6	J-803948	Ring, spark plug cable	1	1
7	J-393594-1	Tip, spark plug cable	5	
8	J-A-6321	End, terminal, coil	1	1
9	JM60359	Coil, ignition	1	
	JM60515	Coil, ignition		1
10	J-631105	Washer, coil bracket	2	2
11	J-GM-120367	Nut, hex.	2	2
12	J-GM-121753	Washer, external tooth	2	2
13	J-A-5083	Cable ass'y, ignition coil (primary)	1	1
14	J-A-1420	Cable ass'y, ignition coil (secondary)	1	1
	JM61002	Cable set, spark plug	1	1

Consists of :

JM60400	1. Cable ass'y, spark plug No. 1
JM60402	1. Cable ass'y, spark plug No. 2
JM60404	1. Cable ass'y, spark plug No. 3
JM60406	1. Cable ass'y, spark plug No. 4
J-A-1420	1. Cable ass'y, ignition coil (secondary)

TRANSMISSION




Fig. 50

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSMISSION				
	J-644315-1	Transmission ass'y	1	1
1	J-53811	Bolt, bearing retainer	3	3
2	J-51875	Gasket	5	5
3	J-640422-1	Retainer, main drive gear bearing	1	1
4	J-645980	Oil seal, bearing retainer	1	1
5	J-640782	Snap ring, bearing	1	1
6	J-640783	Snap ring, main drive gear	1	1
7	J-643721	Bearing, main drive gear	1	1
8	J-640893	Washer, oil retaining front	1	1
9	J-640428	Gear, main drive	1	1
10	J-640786	Roller, needle bearing main shaft	14	14
11	J-642754	Case, transmission	1	1
12	J-GM-147500	Ball, poppet	2	2
13	J-642757	Cap, shift rail	4	4
14	J-642769	Spring, poppet	2	2
15	J-52045	Lockwasher, control housing	6	6
16	J-635868	Bolt, control housing	6	6
17	J-642755-1	Housing, control	1	1
18	J-642758	Plunger, interlock	1	1
19	J-642759	Plug, taper	1	1
20	JM60440-1	Cover	1	1
21	JM60441	Packing	1	1
22	KS300-4	Lockwasher	2	
	M3044-B	Lockwasher		2
23	JM60442	Screw	2	2
24	J-642763	Spring, control lever	1	1
25	J-642770	Gasket, control housing	1	1
26	J-640397	Ring, blocking synchronizer	2	2
27	J-640395	Plate, shifting synchronizer	3	3
28	J-640393	Hub, clutch	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSMISSION (Continued)				
29	J-642766	Fork, shift high and intermediate	1	1
30	J-642768	Pin, shift fork	2	2
31	J-642764	Rail, shift high and intermediate	1	1
32	J-640396	Sleeve, clutch	1	1
33	J-640398	Gear, second speed	1	1
34	J-642767	Fork, shift low and reverse	1	1
35	J-642765	Rail, shift low and reverse	1	1
36	J-640401	Gear, sliding	1	1
37	J-A-1410	Washer, main shaft	1	1
38	J-A-520	Nut, main shaft	1	1
39	JM60218	Bearing, main shaft rear	1	1
40	J-644552	Adapter, main shaft bearing	1	1
41	J-643621	Spacer, main shaft bearing	1	1
42	J-640390	Shaft, main	1	1
43	J-640400	Bushing, second speed gear	1	1
44	J-640394	Spring, synchronizer	2	2
45	J-640431	Snap ring, clutch hub	1	1
46	J-GM-103880	Plug, filler	2	2
47	J-640425	Gasket, bearing retainer	1	1
48	J-640416	Screw, oil collector	2	2
49	J-640413	Collector, oil	1	1
50	J-640409	Washer, thrust countershaft front	1	1
51	J-640405	Gear, countershaft	1	1
52	J-640419	Bushing, reverse idler gear	1	1
53	J-640417	Gear, reverse idler	1	1
54	J-640420	Shaft, reverse idler gear	1	1
55	J-802414	Spacer, countershaft bearing long	1	1
56	J-640778	Spacer, countershaft bearing short	6	6
57	J-640777	Roller, needle bearing countershaft	88	88
58	J-640410	Washer, thrust countershaft rear	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

TRANSMISSION (Continued)

59	J-640411	Washer, thrust countershaft rear	1	1
	J-640779	Washer, thrust countershaft rear	1	1
60	J-640412	Countershaft	1	1
61	J-644316	Plate, lock idler and countershaft	1	1
62	J-644233	Ball, gear shift lever	1	1
63	J-648593-1	Lever, control	1	1
64	J-642761	Ball, fulcrum control lever	1	1
65	J-642762	Pin, fulcrum control lever	1	1
66	JM60339	Packing, control lever.....	1	1
	J-117959	Gasket and oil seal set, transmission	1	1
		Consists of :		
	J-51875	5 Gasket		
	J-642770	1 Gasket, control housing		
	J-640425	1 Gasket, bearing retainer		
	J-644122	1 Gasket, transmission to transference		
	J-645980	1 Oil seal, main drive gear		
	J-805693	Kit, repair, transmission	1	1
		Consists of :		
	J-640425	1 Gasket, bearing retainer		
	J-642770	1 Gasket, control housing		
	J-644122	1 Gasket, transmission to transference		
	J-644316	1 Plate, lock, idler and counter shaft		
	J-640395	3 Plate, shifting, synchronizer		
	J-645980	1 Oil seal, main drive gear		
	J-640431	1 Snap ring, clutch hub		
	J-640783	1 Snap ring, main drive gear		
	J-640786	14 Roller, needle bearing, main shaft		
	J-640394	2 Spring, synchronizer		
	J-640778	6 Spacer, countershaft bearing short		
	J-640893	1 Washer, oil retaining front		

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSMISSION (Continued)				
J-640409		1 Washer, thrust, countershaft front		
J-640410		1 Washer, thrust, countershaft rear		
J-640411		1 Washer, thrust, countershaft rear		
J-804004-1		Kit, control housing	1	1
		Consists of :		
J-GM-147500		2 Ball, poppet		
J-642761		1 Ball, fulcrum control lever		
J-642757		2 Cap, shift rail		
JM60440-1		1 Cover		
J-642766		1 Fork, shift, high and intermediate		
J-642767		1 Fork, shift, low and reverse		
J-642755-1		1 Housing, control		
KS300-4		2 Lockwasher, spring		
J-648593-1		1 Lever, control		
JM60441		1 Packing		
J-642762		1 Pin, fulcrum control lever		
J-643700		1 Pin, guide, control housing		
J-642768		2 Pin, shift fork		
J-642759		1 Plug, taper		
J-642758		1 Plunger, interlock		
JM60442		2 Screw		
J-642769		2 Spring, poppet, shift rail		
J-642764		1 Rail, shift, high and intermediate		
J-642765		1 Rail, shift, low and reverse		
J-642763		1 Spring, support, control lever		




Fig. 51

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSFER CASE				
	J-809287	Case, transfer, ass'y	1	1
1	J-116714	Flange, companion	1	1
2	J-GM-179849	Bolt, hex. hd.	2	2
3	J-649704	Lockwasher, external tooth	20	20
4	J-811687	Seal, felt, output shaft	2	2
5	J-A-958-1	Oil seal, bearing cap	2	2
6	J-A-1134	Gasket, oil seal	2	2
7	J-GM-179848	Bolt, hex. hd.	1	1
8	J-A-985	Bushing, speedometer drive gear	1	1
9	J-A-9330	Cap, output shaft rear bearing	1	1
10	J-A-523	Bolt, hex. hd.	5	5
11	J-A-5707	Gear, speedometer drive	1	1
12	J-A-6753	Shim set, rear bearing cap	1	1
13	J-GM-120228	Bolt, hex. hd.	11	11
14	J-GM-103320	Lockwasher, spring	11	11
15	J-A-1508	Cover, rear	1	1
16	J-A-1509	Gasket, rear cover	1	1
17	J-A-1001	Plate, lock, intermediate shaft	1	1
18	J-809289	Case, transfer	1	1
19	J-GM-122138	Bolt, hex, hd.	4	4
20	J-A-1504	Rod, shift underdrive and direct	1	1
21	J-A-963	Screw, set, shift fork	2	2
22	J-A-967	Plug, poppet	2	2
23	J-A-966-1	Spring, poppet	2	2
24	J-GM-147500	Ball, poppet	2	2
25	J-A-965	Interlock, shift rod	1	1
26	J-A-957	Gasket, bearing cap	1	1
27	J-A-934	Breather	1	1
28	J-801332	Spring, shift lever	2	2
29	J-801330	Lever, shift, underdrive	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSFER CASE (Continued)				
30	J-A-971	Handle, shift lever	2	2
31	J-801331	Lever, shift, front wheel drive.....	1	1
32	J-A-956	Cap, output shaft front	1	1
33	J-A-972	Pin, pivot	1	1
34	J-A-973	Screw, set, pivot pin	1	1
35	J-806431	Fitting	1	1
36	J-A-974	Oil seal, shift rod	2	2
37	J-A-1106	Yoke, end, universal joint.....	1	1
38	J-A-1111	Shield, dust	1	1
39	J-GM-120371	Nut, hex.	1	1
40	J-GM-120384	Lockwasher, spring	1	1
41	J-634758	Insulator, support transfer	1	1
42	J-634759	Snubber, support transfer	1	1
43	J-634762	Washer, mounting transfer	1	1
44	J-A-147	Bolt, support, transfer	1	1
45	J-GM-179839	Bolt, hex. hd.	6	6
46	J-A-962	Rod, shift, front wheel drive	1	1
47	J-A-960	Fork, shift, front wheel drive	1	1
48	J-A-959	Fork, shift, underdrive and direct.....	1	1
49	J-809297	Gear, main shaft	1	1
50	KS310-4035	Pin, cotter	1	
	M390-4 x 35	Pin, cotter		1
51	J-A-1410	Washer, plain	1	1
52	J-A-520	Nut, hex.	1	1
53	J-GM-103880	Plug, pipe	1	1
54	J-A-954	Gasket, bottom cover	1	1
55	J-A-953	Cover, case bottom	1	1
56	J-A-1104	Plug, drain	1	1
57	J-636396	Sleeve, speedometer gear	1	1
58	J-GM-179835	Bolt, hex. hd.	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TRANSFER CASE (Continued)				
59	J-809296	Washer, thrust	2	2
60	J-809292	Shaft, intermediate	1	1
61	J-809295	Spacer, bearing	3	3
62	J-809294	Roller, needle bearing	48	48
63	J-809293	Gear, intermediate	1	1
64	J-A-976	Snap ring, shaft bearing	1	1
65	JM60219	Bearing, clutch shaft	1	1
66	JM60485	Bearing, output shaft ass'y	2	2
67	J-801367	Nut, companion flange	2	2
68	J-A-1028	Washer, companion flange	2	2
69	J-A-1511	Gear, speedometer drive	1	1
70	J-807767	Shaft, nut and washer, output	1	1
71	J-A-987	Bushing, pilot	1	1
72	J-809290	Gear, sliding	1	1
73	J-809291	Gear, output shaft	1	1
74	J-A-990	Washer, thrust	1	1
75	J-A-991	Snap ring, output shaft	1	1
76	J-A-992	Gear, output clutch shaft	1	1
77	J-807892	Shaft, nut and washer, output clutch	1	1
78	J-A-523	Bolt, hex. hd.	1	1
	J-805295-1	Gasket and oil seal set, transfer	1	1
Consists of :				
	J-A-954	1 Gasket, bottom cover		
	J-A-957	1 Gasket, bearing cap		
	J-A-1134	2 Gasket, oil seal		
	J-A-1509	1 Gasket, rear cover		
	J-644122	1 Gasket, transmission to transference		
	J-A-958-1	2 Oil seal, output shaft		
	J-A-974	2 Oil seal, shift rod		
	J-A-7445-1	Oil seal set, transference		1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

TRANSFER CASE (Continued)

Consists of :

J-A-958-1	2 Oil seal, output shaft	
J-A-974	2 Oil seal, shift rod	
J-A-6753	Shim set, rear bearing cap	1

Consists of :

J-A-982	4 Shim. 003" thick	
J-A-983	2 Shim. 010" thick	
J-A-984	2 Shim. 031" thick	

PROPELLER SHAFT




Fig. 52

Key	Parts No.	Nomenclature	No. Req'd J4	J4C
PROPELLER SHAFT				
	JM04084	Shaft, propeller front, ass'y	1	1
	JM04085	Shaft, propeller rear, ass'y	1	1
1	J-A-945	Snap ring, trunnion bearing	10	10
2	J-807780	Journal ass'y	4	4
3	J-120809	Bearing ass'y	16	16
4	J-A-942	Cap, dust	2	2
5	J-A-943	Washer, yoke sleeve	2	2
6	JM01560	Tube, propeller shaft rear, ass'y	1	1
7	J-807693	Yoke, end, universal joint, ass'y	1	1
8	J-A-1445	Yoke, end, universal joint, ass'y	1	1
9	JM01558	Tube, propeller shaft front, ass'y	1	1
10	J-A-490	Bolt, "U" propeller shaft yoke	6	6
11	JM04343	Seal	16	16
12	J-A-491	Nut, hex.	12	12
13	J-GM-120214	Lockwasher	12	12
14	J-A-935	Yoke and plug	2	2
15	J-A-1106	Yoke, end, universal joint	1	1
16	J-A-950	Yoke, propeller shaft flange	1	1
17	JM03093	Fitting	6	6
	J-906929	Kit, universal joint journal	4	4
Consists of :				
	J-807780	1 Journal ass'y		
	J-120809	4 Bearing ass'y		
	J-A-945	4 Snap ring		

FRONT AXLE HOUSING AND SHAFT




Fig. 53

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

FRONT AXLE HOUSING AND SHAFT

1	JM01853	Housing, front axle	1	1
2	J-A-838	Socket, tie rod R.H. ass'y	2	2
3	J-A-837	Clamp, tie rod	4	4
4	JM04090	Crank, bell, steering	1	1
5	J-636035	Nut, hex. L.H.T.	5	5
6	J-649784	Gasket, drive flange	2	2
7	J-A-868	Flange, drive, axle shaft	2	2
8	J-641920	Cap, wheel hub	2	2
9	J-A-760	Bolt, flange to hub	12	12
10	J-GM-103321	Lockwasher	12	12
11	J-A-847	Socket, tie rod L.H. ass'y	1	1
12	J-800611	Kit, shaft and universal joint, L.H.	1	1
Consists of :				
	J-649771	1 Shaft, universal joint, L.H.		
	J-649783	1 Bushing, wheel bearing spindle		
	J-649784	1 Gasket, drive flange		
13	J-642058	Rod, tie, steering, L.H.	1	1
14	J-640178	Socket, tie rod	1	1

STEERING KNUCKLE AND WHEEL BEARING




Fig. 54

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING KNUCKLE AND WHEEL BEARING				
1	J-A-866	Nut, retaining, wheel bearing	4	4
2	J-A-867	Lockwasher, wheel bearing nut	2	2
3	J-A-865	Lockwasher, wheel bearing	2	2
4	J-52942	Cone and roller, wheel bearing	4	4
5	J-52943	Cup, front wheel bearing	4	4
6	J-805150	Oil seal, wheel hub grease	2	2
7	J-A-877	Bolt, brake to steering knuckle	12	12
8	J-GM-120382	Lockwasher, brake to steering knuckle	12	12
9	J-649782	Spindle and bushing, wheel bearing	2	2
10	J-649783	Bushing, wheel bearing	2	2
11	J-GM-103868	Plug, filler	2	2
12	J-805784	Knuckle and arm R.H.	1	1
	J-805783	Knuckle and arm L.H.	1	1
13	JM02641	Shim set, king pin bearing	1	1
		Consists of :		
	JM02370	1 Shim, .13 mm thick		
	JM02371	1 Shim, .25 mm thick		
	JM02372	1 Shim, .75 mm thick		
14	J-A-828	Cap, king pin bearing, ass'y	4	
		Consists of :		
15	J-A-824	1 Pin, king, bearing cap		
16	J-A-825	1 Pin, lock, king pin		
17	J-A-829	1 Cap, king pin bearing		
18	J-802298	Guard, brake hose, front ass'y	2	2
19	J-GM-181374	Bolt, hex. hd.	16	16
20	J-908007	Oil seal, knuckle	2	2
21	J-908008	Ring, seal packing, steering knuckle	2	2
22	J-GM-108629	Pin, cotter	4	4
23	J-GM-102647	Nut, tie rod stud	4	4
24	J-649769	Washer, thrust axle shaft	2	2

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING KNUCKLE AND WHEEL BEARING (Continued)				
25	J-A-821	Bolt, stop, steering knuckle	2	2
26	J-A-873	Nut, lock	2	2
27	JM01853	Housing, front axle	1	1
28	J-52941	Cup, king pin bearing	4	4
29	J-52942	Cone and roller, wheel bearing	4	4
30	J-908005	Oil seal, felt	2	2
31	J-908006	Plate, seal retainer	4	4
32	J-GM-114605	Lockwasher	16	16
33	J-648877	Screw	16	16
34	J-642059	Rod, tie, steering R.H.	1	1
35	J-GM-120368	Nut, tie rod clamp	4	4
36	J-GM-120638	Lockwasher, tie rod clamp	4	4
37	J-A-837	Clamp, tie rod	4	4
38	J-A-875	Bolt, tie rod clamp	4	4
39	J-A-838	Socket, tie rod R.H. ass'y	2	2
40	J-A-844	Cover, dust, tie rod socket	4	4
41	J-A-6305	Spring, tie rod stud	4	4
42	J-GM-103321	Lockwasher	16	16
	J-908226	Kit, steering knuckle oil seal	1	1
		Consists of :		
	J-908005	2 Oil seal, felt		
	J-908006	4 Plate, seal retainer		
	J-908007	2 Oil seal, knuckle		
	J-908008	2 Ring, seal packing, steering		
	JM02474	Oil seal, front axle shaft	2	2




Fig. 55

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FRONT AXLE				
	J-649761	Axle, front, ass'y (with brakes, hubs and drums)	1	1
	JM02635	Axle, front, ass'y (Does not include brakes, hubs and drums)	1	1
1	J-52881	Cup, differential bearing	2	2
2	J-52880	Cone and roller, differential bearing	2	2
3	JM02639	Shim set, adjusting differential	1	1
	Consists of :			
	JM02359	2 Shim, .07mm thick		
	JM02360	2 Shim, .13mm thick		
	JM02361	2 Shim, .25mm thick		
	JM02362	2 Shim, .75mm thick		
4	J-A-793	Case, differential	1	1
5	JM05092	Gear set, axle drive gear and pinion	1	1
6	J-807266	Cone and roller, pinion bearing	1	1
7	J-52877	Cup, pinion bearing	1	1
8	JM02640	Shim set, adjusting pinion bearing	1	1
	Consists of :			
	JM02363	2 Shim, .07mm thick		
	JM02364	2 Shim, .13mm thick		
	JM02365	2 Shim, .25mm thick		
	JM02366	2 Shim, .07mm thick		
	JM02367	2 Shim, .13mm thick		
	JM02368	2 Shim, .25mm thick		
	JM02369	1 Shim, .75mm thick		
9	JM01853	Housing, front axle	1	1
10	J-52879	Cup, pinion bearing	1	1
11	J-52878	Cone and roller, pinion bearing	1	1
12	J-636566	Slinger, oil	1	1
13	J-636565	Gasket, oil seal pinion	1	1
14	JM02475	Oil seal, pinion	1	1
15	J-636568	Shield, dust, universal yoke	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FRONT AXLE (Continued)				
16	J-A-1446	Yoke, end, universal joint	1	1
17	J-636570	Washer, pinion nut	1	1
18	J-801367	Nut, hex.	1	1
19	J-636577	Plug, drain	1	1
20	J-A-797	Washer, thrust, pinion mate	2	2
21	JM05750	Gear set, differential	1	1
22	JM03264	Washer, thrust, side gear	2	2
23	J-A-782	Gasket, housing cover	1	1
24	JM01906	Cover, . housing	1	1
25	J-GM-108579	Lockwasher	10	10
26	J-GM-179814	Bolt, hex. hd.	10	10
27	J-GM-103869	Plug, filler	1	1
28	JM01908	Breather, axle housing	1	1
29	J-636360	Pin, lock, pinion shaft	1	1
30	J-A-798	Shaft, case pinion	1	1
31	J-A-792	Strap, lock	4	4
32	JM02873	Screw, axle drive gear	8	8
	JM05103	Kit, axle drive gear and pinion	1	1
		Consists of :		
	JM05092	1 Gear set		
	JM02873	8 Screw		
	J-A-792	4 Strap		
	J-801929	Differential ass'y	1	1
33	J-649771	Shaft, universal joint, L. H. ass'y	1	1
	J-649772	Shaft, universal joint, R. H. ass'y	1	1
34	J-636527	Bolt, hex. hd.	4	4
35	JM01907	Elbow	1	1
	JM05277	Gasket set, front axle, contains all gaskets & seals required to repair front axle	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

FRONT AXLE (Continued)

J-A-782	1 Gasket
JM02475	1 Oil seal
J-636565	1 Gasket
JM02474	2 Oil seal
J-805150	2 Oil seal
J-908226	1 Kit, steering knuckle oil seal
J-649784	2 Gasket

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
REAR AXLE				
	J-802895	Axle, rear ass'y (with brakes, hubs and drums)	1	1
	JM02636	Axle, rear ass'y (Does not include brakes, hubs and drums)	1	1
1	JM01815	Cup, differential bearing	2	2
2	JM01816	Cone and roller, differential bearing	2	2
3	JM02639	Shim set, adjusting, differential	1	1
	Consists of:			
	JM02359	2 Shim, .07 mm thick		
	JM02360	2 Shim, .13 mm thick		
	JM02361	2 Shim, .25 mm thick		
	JM02362	2 Shim, .75 mm thick		
4	J-802562	Case, differential	1	1
5	JM05093	Gear set, axle drive gear and pinion	1	1
6	J-807266	Cone and roller, pinion bearing	1	1
7	J-52877	Cup, pinion bearing	1	1
8	JM02640	Shim set, adjusting pinion bearing	1	1
	Consists of:			
	JM02363	2 Shim, .07 mm thick		
	JM02364	2 Shim, .13 mm thick		
	JM02365	2 Shim, .25 mm thick		
	JM02366	2 Shim, .07 mm thick		
	JM02367	2 Shim, .13 mm thick		
	JM02368	2 Shim, .25 mm thick		
	JM02369	1 Shim, .75 mm thick		
9	JM03092	Fitting	2	2
10	JM01854	Housing, rear axle	1	1
11	J-636527	Bolt, hex. hd.	4	4
12	J-636528	Lockwasher	4	4
13	J-52879	Cup, pinion bearing	1	1
14	J-52878	Cone and roller, pinion bearing	1	1
15	J-802564	Slinger, oil	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
REAR AXLE (Continued)				
16	J-636565	Gasket, oil seal pinion	1	1
17	JM02475	Oil seal, pinion	1	1
18	J-642121	Shield, dust, universal yoke	1	1
19	J-A-1446	Yoke, end, universal joint	1	1
20	J-636570	Washer, pinion nut	1	1
21	J-801367	Nut, hex.	1	1
22	JM02644	Shim set, rear axle shaft bearing	1	1
		Consists of:		
	JM02356	2 Shim, .13 mm thick		
	JM02357	3 Shim, .25 mm thick		
	JM02358	2 Shim, .75 mm thick		
23	J-52800	Cup, shaft bearing	2	2
24	J-52799	Cone and roller, shaft bearing	2	2
25	JM02473	Oil seal, carrier end	2	2
26	J-636577	Plug, drain, axle housing	1	1
27	J-645790	Washer, thrust, pinion mate	2	2
28	JM05751	Gear set, differential	1	1
29	JM03263	Washer, thrust, side gear	2	2
30	J-640969	Shaft, rear axle R.H.	1	1
	J-640968	Shaft, rear axle L.H.	1	1
31	J-640965	Spacer, drive shaft	1	1
32	J-802556	Gasket, housing cover	1	1
33	J-802897	Cover, housing	1	1
34	J-GM-108579	Lockwasher	10	10
35	J-GM-179814	Screw, hex. hd.	8	8
36	J-GM-103869	Plug, filler	1	1
37	J-GM-179816	Screw, hex. hd.	2	2
38	J-802509	Bracket, tee	1	1
39	J-636360	Pin, lock, pinion shaft	1	1
40	J-636553	Shaft, case pinion	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

REAR AXLE (Continued)

41	J-802561	Strap, lock, drive gear screw	5	5
42	JM02873	Screw, axle drive gear	10	10
	JM05104	Kit, axle drive gear and pinion	1	1
		Consists of :		
	JM05093	1 Gear set		
	JM02873	10 Screw		
	J-802561	5 Strap		
	JM05278	Gasket set, rear axle, contains all gaskets		
		& seals required to repair rear axle	1	1
		Consists of :		
	J-802556	1 Gasket		
	J-636565	1 Gasket		
	JM02475	1 Oil seal		
	JM02473	2 Oil seal		

HAND BRAKE

	J-642776	Brake ass'y, hand	1	1
1	J-GM-120368	Nut, hex.	4	4
2	J-GM-120214	Lockwasher	3	3
3	J-GM-446363	Washer, plain	3	3
4	J-GM-123473	Bolt, hex. hd.	2	2
5	JM04105	Pull rod ass'y, hand brake	1	1
6	J-648591	Fastener, cable conduit to flywheel housing	1	1
7	JM04106	Cable and conduit ass'y, ratchet tube	1	1
8	JM04282	Clip	1	1
9	JM04126	Brace, ratchet tube bracket	1	1
10	J-GM-123774	Bolt, hex. hd.	1	1
11	J-GM-120214	Lockwasher	1	1
12	J-A-8847	Clamp, conduit to cross member	1	1
13	J-GM-120368	Nut, hex.	1	1

HAND BRAKE




Fig. 57

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
HAND BRAKE (Continued)				
14	J-GM-144242	Clevis, adjustable	1	1
15	J-A-17254	Lever ass'y, operating hand brake	1	1
16	J-A-10052	Gasket, backing plate to rear bearing cap	1	1
17	J-GM-123391	Bolt, hex. hd.	1	1
18	J-GM-120382	Lockwasher	1	1
19	J-A-10332	Screw, adjusting R.H.T.	1	1
20	J-A-10330	Bracket, adjusting screw, ass'y	1	1
21	J-A-10331	Screw, adjusting L.H.T.	1	1
22	J-A-10338	Spring, return brake shoe adjusting end	1	1
23	J-A-10334	Link, operating lever	1	1
24	J-GM-427298	Nut, hex.	1	1
25	J-A-10335	Nut, hex.	1	1
26	JM02069	Washer, plain	2	2
27	J-A-10333	Lever, brake cam	1	1
28	J-A-9332	Drum, hand brake	1	1
29	J-A-6084	Bolt, hex. hd.	4	4
30	J-GM-103321	Lockwasher	4	4
31	J-GM-103026	Nut, hex.	4	4
32	J-A-935	Yoke and plug	1	1
33	J-A-950	Yoke, propeller shaft flange	1	1
✓ 34	J-801367	Nut, companion flange	1	1
35	J-A-1028	Washer, plain	1	1
36	J-116714	Flange and oil seal, guard	1	1
37	J-A-10337	Spring, return brake shoe lever end	1	1
38	J-643055	Shoe and lining set, hand brake	1	1
Consists of :				
	J-A-10324	2 Shoe and lining ass'y		
39	JM02041	Plate, backing hand brake	1	1
40	J-636396	Sleeve, speedometer gear	1	1
41	J-A-5707	Gear, speedometer driven	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HAND BRAKE (Continued)

42	J-A-985	Bushing, speedometer drive gear	1	1
43	J-A-9330	Cap ass'y, bearing, output shaft rear	1	1
44	J-A-5335	Spring, retracting, hand brake	1	1
45	J-640680	Link, retracting spring	1	1
46	J-GM-137159	Pin, cotter	1	1
47	J-311003	Pin, clevis, cable to operating lever	1	1
48	J-641921	Clip, retracting spring	1	1
49	J-A-10336	Spring, operating lever spacer	1	1
	JM03744	Lining set, hand brake	1	1
		Consists of :		
	JM03745	2 Lining		
	J-640102	20 Rivet		
	J-A-17253	Bushing, operating lever	1	1
	J-GM-119252	Nut, castle (Brake operating lever pivot)	1	1
	J-A-9338	Washer, plain (Brake operating lever pivot)	1	1
	J-GM-103373	Pin, cotter (Brake operating lever pivot)	1	1

WHEEL BRAKE

	J-807281	Brake ass'y, front L.H.	1	1
	J-807282	Brake ass'y, front R.H.	1	1
	J-807283	Brake ass'y, rear L.H.	1	1
	J-807284	Brake ass'y, rear R.H.	1	1
1	J-807356	Cylinder, front wheel brake ass'y	2	2
	J-807357	Cylinder, rear wheel brake ass'y	2	2
2	J-GM-121797	Bolt, hex. hd.	8	8
3	J-GM-121753	Lockwasher	8	8
4	J-637905	Spring, return, brake shoe cylinder end	4	4
5	J-A-877	Bolt, hex. hd. (Front brake to steering knuckle)	12	12
6	J-GM-120382	Lockwasher	32	32
7	J-909393	Nut, hex. (Rear brake to axle housing)	12	12

WHEEL BRAKE




Fig. 58

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

WHEEL BRAKE (Continued)

8	JM02119	Bolt, hex. hd. (Rear brake to axle housing)	12	12
9	J-805592	Eccentric, wheel brake shoe	8	8
10	J-GM-120369	Nut, hex.	8	8
11	J-807371	Shoe, brake ass'y	8	8
12	<u>J-116551</u>	Lining, brake shoe forward	4	4
13	JM03749	Lining, brake shoe reverse	4	4
14	J-374586	Rivet	80	80
15	J-391404	Cup, shoe hold down spring	16	16
16	J-636863	Spring, hold down, brake shoe	8	8
17	J-807374	Pin, hold down spring	8	8
18	J-805602	Spring, return, brake shoe, anchor end	4	4
19	J-807366	Plate, backing, brake ass'y	4	4
	<u>JM03742</u>	Kit, brake shoe and lining	2	2
		Consists of :		
	J-807369	2 Shoe and lining, forward		
	J-807370	2 Shoe and lining, reverse		
	<u>JM03743</u>	Lining set, brake shoe	2	2
		Consists of :		
	<u>J-116551</u>	2 Lining, forward		
	JM03749	2 Lining, reverse		
	J-374586	42 Rivet		

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
WHEEL BRAKE CYLINDER				
	J-807356	Cylinder, front wheel brake, ass'y	2	2
	J-807357	Cylinder, rear wheel brake, ass'y	2	2
1	J-802550	Boot, front wheel brake cylinder	4	4
	J-802551	Boot, rear wheel brake cylinder	4	4
2	J-642013	Piston, front brake cylinder ass'y	4	4
	J-807411	Piston, rear brake cylinder ass'y	4	4
3	J-637579	Cup, front wheel brake cylinder	4	4
	J-A-6116	Cup, rear wheel brake cylinder	4	4
4	J-639949	Spring, front brake cylinder cup	2	2
	J-637545	Spring, rear brake cylinder cup	2	2
5	J-A-1737	Cylinder, front wheel brake	2	2
	J-A-6112	Cylinder, rear wheel brake	2	2
6	J-648674	Screw, bleeder	4	4
	<u>11 JM03781 (P)</u>	<u>Kit, front wheel brake cylinder</u>	<u>2</u>	<u>2</u>
		Consists of :		
	J-802550	2 Boot, front cylinder		
	J-637579	2 Cup, front cylinder		
	<u>11 JM03782 (P)</u>	<u>Kit, rear wheel brake cylinder</u>	<u>2</u>	<u>2</u>
		Consists of :		
	J-802551	2 Boot, rear cylinder		
	J-A-6116	2 Cup, rear cylinder		

WHEEL BRAKE CYLINDER

MASTER CYLINDER BRAKE




Fig. 59

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

MASTER CYLINDER BRAKE

	J-805223	Cylinder, master, ass'y	1	1
1	J-647282	Rod, push, master cylinder	1	1
2	J-647283	Boot, master cylinder	1	1
3	J-637598	Wire, lock, piston stop	1	1
4	J-637597	Plate, stop, master cylinder piston	1	1
5	J-637286	Piston, master cylinder	1	1
6	J-637590	Cup, primary	1	1
7	JM01953	Spring and valve ass'y	1	1
8	J-637583	Seat, valve, ass'y	1	1
9	J-643671	Tank, supply	1	1
10	J-637612	Gasket, filler cap	1	1
11	J-118493	Cap, filler	1	1
12	J-637604	Gasket, outlet fitting to master cylinder	1	1
13	J-A-557	Fitting, outlet	1	1
14	J-637606	Gasket, outlet bolt to outlet fitting	1	1
15	J-637605	Bolt, outlet fitting	1	1
	J-811645	Valve, check ass'y	1	1
	J-805654	Kit, repair master cylinder	1	1

Consists of :

J-647283	1 Boot
J-637590	1 Cup
J-647286	1 Piston ass'y
J-637583	1 Seat, valve
J-811645	1 Valve, check ass'y
J-637598	1 Wire, lock

117
1122

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HYDRAULIC BRAKE SYSTEM

1	J-807356	Cylinder, front wheel brake ass'y	2	2
2	J-A-1488	Pipe, brake (Front wheel cylinder to axle hose)	2	2
3	<u>J-A-15802</u>	Hose, front axle pipe to front brake pipe	2	2
4	J-801394	Pipe, brake, ass'y (Tee to front brake hose R.H.)	1	1
5	J-A-1378	Clip, under front axle cover bolt	2	2
6	J-804201	Clip, brake pipe to axle housing	3	3
7	J-A-15801	Hose, master cylinder pipe to front brake pipe	1	1
8	J-A-8848	Spacer, front axle tee to axle bracket	1	1
9	J-801393	Pipe, brake, ass'y (Tee to front brake hose L.H.)	1	1
10	J-637432	Tee, axle brake pipe	2	2
11	J-647915	Pipe, brake, ass'y (Master cylinder to front hose)	1	1
12	J-806162	Shield, master cylinder, ass'y	1	1
13	J-647283	Boot, master cylinder	1	1
14	J-647606	Bolt, eye, master cylinder to pedal	1	1
15	J-647544	Pipe, brake, ass'y (Master cylinder to rear hose)	1	1
16	J-805223	Cylinder, master, ass'y	1	1
17	J-645539	Clip, brake pipes to frame	4	4
18	J-807357	Cylinder, rear wheel brake, ass'y	2	2
19	J-640942	Pipe, brake, ass'y (Tee to left rear brake)	1	1
20	J-640943	Pipe, brake, ass'y (Tee to right rear brake)	1	1
21	J-GM-125912	Clip, under rear axle cover bolt	1	1
22	<u>J-A-15803</u>	Hose, rear brake ass'y	1	1
23	J-637427	Clip, spring lock "U" type	6	6
24	J-637426	Gasket, brake hose to brake and axle tee	2	2
25	J-800527	Pedal, brake ass'y	1	1
26	J-A-6360	Washer, pedal shank draft pad	1	1
27	J-905860	Pad, brake pedal, ass'y	1	1
28	J-807208	Pad, draft pedal shank	1	1
29	J-GM-122027	Screw, hex. hd.	1	1
30	J-GM-120214	Lockwasher	1	1

HYDRAULIC BRAKE SYSTEM




Fig. 60

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HYDRAULIC BRAKE SYSTEM (Continued)

31	JM03092	Fitting.....	1	1
32	J-A-495	Shaft, brake pedal, ass'y	1	1
33	J-GM-137228	Pin, cotter, brake pedal to shaft	2	2
34	J-A-498	Washer, pedal shaft	1	1
35	J-630593	Spring, retracting brake pedal	1	1
36	J-GM-120395	Washer, plain	1	1
37	J-GM-121222	Pin, cotter	1	1
	JM03093	Fitting	1	1
38	J-650684	Spring	1	1

FRONT WHEEL AND ATTACHING PARTS

1	J-641920	Cap, wheel hub	2	2
2	J-A-760	Bolt, hex. hd.	12	12
3	J-A-868	Flange, drive, axle shaft	2	2
4	J-649784	Gasket, drive flange	2	2
5	J-A-866	Nut, retaining, wheel bearing	4	4
6	J-A-867	Lockwasher, wheel bearing nut	2	2
7	J-A-865	Lockwasher, wheel bearing nut	2	2
8	J-52942	Cone and roller, wheel bearing	4	4
9	J-52943	Cup, front wheel bearing	4	4
10	J-649874	Hub and drum, front wheel R.H.	1	1

Consists of :

J-649938	1 Hub, front, ass'y R.H.
J-GM-137991	3 Screw, fl. hd.
J-808769	1 Drum, front and rear wheel brake
J-649873	Hub and drum, front wheel L.H.

1 1

Consists of :

J-649937	1 Hub, front, ass'y L.H.
J-GM-137991	3 Screw, fl. hd.
J-808769	1 Drum, front and rear wheel brake

FRONT WHEEL AND ATTACHING PARTS




Fig. 61

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J+C

FRONT WHEEL AND ATTACHING PARTS (Continued)

11	J-805150	Oil seal, front hub	2	2
12	J-807281	Brake ass'y, front L.H.	1	1
	J-807282	Brake ass'y, front R.H.	1	1
13	J-649782	Spindle and bushing, wheel bearing ass'y	2	2
14	J-805784	Knuckle and arm R.H.	1	1
	J-805783	Knuckle and arm L.H.	1	1
15	J-649769	Washer, thrust, axle shaft	2	2
16	J-800612	Kit, shaft and universal joint R.H.	1	1
		Consists of :		
	J-649772	1 Shaft and universal joint R.H.		
	J-649783	1 Bushing, wheel bearing spindle		
	J-649784	1 Gasket, drive flange		
17	J-GM-120382	Lockwasher (Front brake to steering knucle)	12	12
18	J-A-877	Bolt, hex. hd. (Front brake to steering knucle)	12	12
19	J-GM-137991	Screw, ctsk. hd.	6	6
20	J-636035	Nut, hex. L.H.T. wheel hub bolt	5	5
	J-635516	Nut, hex. R.H.T. wheel hub bolt	5	5
21	J-GM-103321	Lockwasher	12	12
	JM01198	Wheel, disc	2	2

No. Reg'd
U.S. Pat. Off.
— 159 —

REAR WHEEL AND ATTACHING PARTS




Fig. 62

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J40


REAR WHEEL AND ATTACHING PARTS

1	JM02473	Oil seal, axle shaft carrier end	2	2
2	J-52799	Cone and roller, shaft bearing	2	2
3	J-52800	Cup, shaft bearing	2	2
4	JM02644	Shim set, rear axle shaft bearing	1	1
		Consists of :		
	JM02356	2 Shim, .13 mm thick		
	JM02357	3 Shim, .25 mm thick		
	JM02358	2 Shim, .75 mm thick		
5	J-802887	Retainer, axle shaft bearing	2	2
6	J-807284	Brake ass'y, rear R.H.	1	1
	J-807283	Brake ass'y, rear L.H.	1	1
7	J-640886	Gasket, rear brake grease protector	4	4
8	J-646239	Retainer, grease, axle shaft ass'y	2	2
9	J-640888	Protector, grease, rear brake	2	2
10	J-649878	Bolt, hex. hd. R.H.	5	5
	J-649877	Bolt, hex. hd. L.H.	5	5
11	J-801708	Hub and drum ass'y, rear wheel R.H.	1	1
		Consists of :		
	J-808784	1 Hub, rear ass'y		
	J-GM-137991	3 Screw, fl. hd.		
	J-808769	1 Drum, front and rear wheel brake		
	J-801707	Hub and drum ass'y, rear wheel L.H.	1	1
		Consists of :		
	J-808783	1 Hub, rear ass'y		
	J-GM-137991	3 Screw, fl. hd.		
	J-808769	1 Drum, front and rear wheel brake		
12	J-636374	Key, rear axle shaft	2	2
13	J-640945	Washer, rear axle shaft	2	2
14	J-636344	Nut, hex.	2	2
15	J-GM-137204	Pin, cotter	2	2

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C


REAR WHEEL AND ATTACHING PARTS (Continued)

16	J-641920	Cap, wheel hub	2	2
17	J-GM-137991	Screw	6	6
18	J-909393	Nut, hex.	12	12
19	J-GM-120382	Lockwasher	12	12
20	JM02119	Bolt, hex. hd.	12	12
	JM01198	Wheel disc	2	2




Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING				
1	J-GM-124155	Bolt, hex. hd.	3	3
2	J-GM-178571	Lockwasher	6	6
3	J-GM-120370	Nut, hex.	3	3
4	J-809723	Shim, 0.25 mm thick	As req'd	
5	J-803203	Shim, 1.00 mm thick	As req'd	
6	J-803202	Shim, 3.20 mm thick	As req'd	
7	J-666524	Grommet, steering column	1	1
8	J-A-1276	Clamp, steering column support	1	1
9	J-GM-120741	Bolt, hex. hd.	4	4
10	J-GM-138485	Lockwasher	4	4
11	J-A-1277	Bushing, steering column support	1	1
12	J-808571	Support, steering column	1	1
13	J-GM-120368	Nut, hex.	4	4

STEERING SYSTEM



Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING SYSTEM				
1	J-642057	Rod, tie, steering R.H. ass'y	1	1
2	J-A-838	Socket, tie rod R.H. ass'y.....	2	2
3	J-805784	Knuckle and arm R.H.	1	1
4	JM03092	Fitting	1	1
5	J-646619	Rod, connecting, steering ass'y	1	1
6	J-A-1116	Arm, steering	1	1
7	J-647694	Gear, steering	1	1
8	J-805783	Knuckle and arm L.H.	1	1
9	J-A-847	Socket, tie rod L.H. ass'y	1	1
10	J-642056	Rod, tie, steering L.H. ass'y	1	1
11	J-640178	Socket, tie rod	1	1
12	J-GM-124145	Bolt, bell crank	1	1
13	J-645664	Bearing, bell crank	2	2
14	JM04091	Cap	1	1
15	JM04092	Seal, bell crank	1	1
16	J-GM-131018	Washer, bell crank shaft	1	1
17	J-645663	Seal, bell crank bearing	2	2
18	J-GM-120370	Nut, hex.	1	1
19	J-GM-131016	Washer, plain	1	1
20	J-649240	Nut, hex.	1	1
21	J-GM-120383	Lockwasher	1	1
22	JM04090	Crank, bell	1	1
23	JM04095	Shaft, bell crank	1	1
24	JM04094	Spacer, bell crank	1	1
	JM04462	Kit, steering bell crank	1	1
Consists of :				
	J-645664	2 Bearing, bell crank		
	J-645663	2 Seal, bell crank		
	JM04095	1 Shaft, bell crank		
	JM04094	1 Spacer, bell crank		
	JM04092	1 Seal, bell crank		

TIE ROD STEERING



STEERING CONNECTING ROD




Fig. 65

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
TIE ROD STEERING				
1	J-GM-108629	Pin, cotter	4	4
2	J-GM-102647	Nut, hex.	4	4
3	J-A-6305	Spring, tie rod stud	4	4
4	J-A-844	Cover, dust tie rod socket	4	4
5	J-A-847	Socket, tie rod L.H. ass'y	1	1
6	J-GM-120368	Nut, hex.	4	4
7	J-GM-120638	Lockwasher	4	4
8	J-642058	Rod, tie, steering L.H.	1	1
9	JM01817	Fitting	4	4
10	J-640178	Socket, tie rod	1	1
11	J-642059	Rod, tie, steering R.H.	1	1
12	J-A-838	Socket, tie rod R.H. ass'y	2	2
13	J-A-875	Bolt, hex. hd.	4	4
14	J-A-837	Clamp, tie rod	4	4

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

STEERING CONNECTING ROD

1	J-GM-137214	Pin, cotter	2	2
2	J-630756	Plug, large	1	1
3	J-630755	Seat, ball	3	3
4	J-630754	Spring, ball seat	2	2
5	J-630753	Plug, spring	2	2
6	J-A-622	Cover, dust	2	2
7	J-A-623	Shield, dust	2	2
8	J-630757	Plug, adjusting, small	1	1
9	JM03092	Fitting	2	2
10	J-646620	Rod, connecting	1	1
	J-800695	Kit, steering connecting rod	1	1

Consists of :

J-630756	1 Plug, large
J-630757	1 Plug, adjusting small
J-630753	2 Plug, spring
J-630755	3 Seat, ball
J-630754	2 Spring, ball seat

STEERING GEAR




Fig. 66

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING GEAR				
1	J-639115	Nut, shaft, steering gear lever	1	1
2	J-GM-103325	Lockwasher	1	1
3	J-A-1116	Arm, steering gear	1	1
4	JM02453	Oil seal, lever shaft	1	1
5	J-639091	Bushing, housing, inner	1	1
6	J-639090	Bushing, housing, outer	1	1
7	J-GM-103865	Plug, filler	1	1
8	J-639092	Cover and tube	1	1
9	J-639103	Ring, retaining	2	2
10	J-639102	Cup, ball, cam bearing	2	2
11	J-639104	Ball	22	22
12	J-647693	Tube and cam	1	1
13	J-A-6760	Shim set, housing, upper cover	1	1
Consists of :				
	J-639108	2 Shim, .05 mm thick		
	J-639109	2 Shim, .08 mm thick		
	J-639110	2 Shim, .25 mm thick		
14	J-A-1760	Cover, upper	1	1
15	J-GM-120638	Lockwasher	5	5
16	J-639107	Bolt, hex. hd.	3	3
17	JM02548	Wheel, steering	1	1
18	J-804623	Button, horn	1	1
19	J-801427	Cap, contact, horn button	1	1
20	J-801425	Nut, steering wheel	1	1
21	J-639121	Lockwasher	2	2
22	J-638884	Spring, horn button	1	1
23	J-638885	Cup, horn button spring	1	1
24	J-639191	Spring, column bearing	1	1
25	J-801423	Seat, bearing spring	1	1
26	J-801422	Bearing, steering column	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
STEERING GEAR (Continued)				
27	J-801428	Cable and terminal, horn	1	
	JM06414	Cable and terminal, horn		1
28	J-647690	Column and bearing	1	1
29	J-666524	Grommet, steering column	1	1
30	J-GM-123798	Bolt, hex. hd.	1	1
31	J-A-636	Clamp, steering column	1	1
32	J-GM-138538	Lockwasher	1	1
33	J-GM-120368	Nut, hex.	1	1
34	J-639118	Screw, adjusting	1	1
35	J-GM-124929	Nut, hex.	1	1
36	J-639120	Bolt, hex. hd.	4	4
37	J-639117	Cover, side, gear housing	1	1
38	J-639119	Gasket, side cover	1	1
39	J-A-745	Shaft and lever	1	1
40	J-646289	Housing ass'y	1	1
	JM02619	Kit, steering gear shaft and lever	1	1
		Consists of :		
	J-639090	2 Bushing, housing inner		
	J-639119	1 Gasket, side cover		
	JM02453	1 Oil seal, lever shaft		
	J-A-745	1 Shaft and lever		

FRAME




Fig. 67

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FRAME				
	JM01283	Frame ass'y	1	1
1	J-645119	Bar, bumper, front	1	1
2	JM00702	Bracket ass'y, battery box	1	1
3	J-645071	Outrigger, body, No.1 R.H.	1	1
4	J-645072	Outrigger, body, No.2 and No.3	4	4
5	J-647418	Reinforcement, rear	1	1
6	JM01281	Cross member, rear	1	1
7	J-A-544	Bracket, shackle, front and rear	4	4
8	J-647350	Bracket, rear shock absorber	2	2
9	J-A-500	Bracket, pivot, front and rear	4	4
10	J-645702	Outrigger, body, No.1 L.H.	1	1
11	J-801662	Bracket, retainer, pedal shaft	1	1
12	J-A-1283	Bracket, front brake hose	1	1
13	J-647454	Bracket, front shock absorber	2	2
14	J-646932	Bracket, radiator guard	2	2
15	J-647030	Tube, cross frame	1	1
16	J-808964	Bracket, support, engine R.H.	1	1
17	J-647919	Bracket, support, engine L.H.	1	1
18	J-649705	Cross member, support, rear	1	1
19	J-A-1150	Cross member, frame center	1	1
20	J-646942	Cross member, intermediate, rear	1	1
21	JM04082	Bracket, bell crank	1	1
22	JM04101	Hook, towing	1	
23	J-GM-121615	Bolt, hex. hd.	3	3
24	J-GM-120381	Lockwasher	3	3
25	J-GM-120369	Nut, hex.	9	9
26	J-646933	Bracket, support	2	2
27	J-GM-124169	Bolt, hex. hd.	2	
28	J-GM-120384	Lockwasher	2	
29	J-GM-120371	Nut, hex.	2	

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FRAME (Continued)				
30	J-646943	Member, side frame L.H.	1	1
31	J-646944	Member, side frame R.H.	1	1
32	J-GM-120758	Bolt, hex. hd.	4	4
33	JM03191	Strap, lock	4	4
34	J-GM-120647	Bolt, hex. hd.	2	2
35	JM00819	Lockwasher	6	6
36	J-640689	Plate, skid, under frame	1	1
37	J-GM-126390	Bolt, rd. hd.	4	4
38	J-GM-120394	Washer, plain	4	4
39	J-GM-120377	Nut, hex.	4	4

PINTLE HOOK

1	JM00265	Hook ass'y	1	1
2	J-GM-120919	Bolt, hex. hd.	2	2
3	J-GM-271506	Nut, hex.	2	2
4	J-GM-120383	Lockwasher	2	2
5	JM00266	Hook, pintle	1	1
6	JM00267	Latch, pintle hook	1	1
7	JM00271	Bolt, hex. hd.	1	1
8	JM00272	Nut, hex.	1	1
9	J-GM-120383	Lockwasher	2	2
10	JM00269	Pin	1	1
11	JM00268	Trip, pintle hook	1	1
12	JM00270	Spring, latch, pintle hook	1	1
13	JM00274	Eyelet	2	2
14	J-GM-120378	Nut, hex.	2	2
15	J-GM-120384	Lockwasher	2	2

PINTLE HOOK




Fig. 68

LIFTING SHACKLE AND TYDOWN BRACKET (J4C)





Fig. 69

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

LIFTING SHACKLE AND TYDOWN BRACKET (J4C)

	JM06081	Lifting shackle ass'y, front	2	
	JM06088	Lifting shackle ass'y, rear	2	
1	JM06086	Lifting shackle, front	2	
2	JM06090	Lifting shackle, rear	2	
3	JM06082	Bracket, lifting shackle front	2	
4	JM06089	Bracket, lifting shackle rear	2	
5	JM06085	Pin, lifting shackle	4	
6	JM06087	Chain, ass'y	4	
7	J-GM-124169	Bolt, hex. hd.	2	
8	J-GM-120424	Bolt, hex. hd.	2	
9	J-GM-120384	Lockwasher	8	
10	J-GM-120371	Nut, hex.	4	
11	J-GM-123605	Bolt, hex. hd.	4	
	JM06091	Tydown bracket ass'y	4	
12	JM06092	Bracket, tydown	4	
13	J-GM-123567	Bolt, hex. hd.	8	
14	J-GM-120380	Lockwasher	8	



Key	Parts No.	Nomenclature	No. Req'd J4	No. Req'd J4C
FRONT SPRING AND SHOCK ABSORBER				
1	JM02182	Spring ass'y, front 2	2	2
		Consists of :		
	JM02182-1	1 Leaf, front spring No. 1		
	JM02182-2	1 Leaf, front spring No. 2		
	JM02182-3	1 Leaf, front spring No. 3		
	JM02182-4	1 Leaf, front spring No. 4		
	JM02182-5	1 Leaf, front spring No. 5		
	JM02182-6	1 Leaf, front spring No. 6		
	JM02182-7	1 Leaf, front spring No. 7		
	JM02182-8	1 Leaf, front spring No. 8		
	JM02182-9	1 Leaf, front spring No. 9		
	JM02182-10	1 Leaf, front spring No.10		
	JM02182-11	1 Bushing, eye		
	JM02182-12	1 Nut, center bolt		
	JM02182-13	1 Bolt, center		
	JM02182-14	2 Clip, inner		
	JM02182-15	2 Clip, outer		
	JM02182-19	4 Rivet		
2	J-384228	Bolt, pivot 2	2	2
3	JM01155	Nut, hex. 2	2	2
4	J-GM-137185	Pin, cotter 2	2	2
5	JM03092	Fitting 6	6	6
6	J-A-513	Bolt, "U" spring shackle L.H.T. (Left, front) 1	1	1
7	J-A-514	Bolt, "U" spring shackle R.H.T. (Right, front) 1	1	1
8	JM01471	Bushing, spring shackle L.H.T. 1	1	1
9	JM01470	Bushing, spring shackle R.H.T. 3	3	3
10	J-A-1252	Retainer, grease seal 4	4	4
11	J-A-515	Seal, grease 4	4	4
12	J-A-572	Plate and shaft L.H. 1	1	1
13	J-A-568	Plate and shaft R.H. 1	1	1

Key	Parts No.	Nomenclature	No. Req'd J4	No. Req'd J4C
FRONT SPRING AND SHOCK ABSORBER (Continued)				
14	JM02916	Bolt, "U" spring	3	3
15	JM02917	Bolt, "U" spring	1	1
16	JM01154	Lockwasher	8	8
17	J-339372	Nut, clip to axle	8	8
18	J-637936	Bushing, mounting pin	8	8
19	JM02440	Absorber, shock, front	2	
	JM06646	Absorber, shock, front		2
20	J-641916	Washer, mounting pin	4	4
21	J-GM-103407	Pin, cotter	4	4
22	JM02182-11	Bushing, eye	2	2
23	JM01473	Bushing, spring shackle L.H.T.	1	1
24	JM01472	Bushing, spring shackle R.H.T.	3	3
25	J-906826	Bumper, axle	2	2
	J-802061	Kit, spring shackle "U" bolt L.H.T.	1	1
		Consists of :		
	J-A-513	1 Bolt, "U" L.H.T.		
	JM01471	1 Bushing, L.H.T.		
	JM01470	1 Bushing, R.H.T.		
	J-A-1252	2 Retainer		
	J-A-515	2 Seal, grease		
	J-802062	Kit, spring shackle "U" bolt R.H.T.	1	1
		Consists of :		
	J-A-514	1 Bolt, "U" R.H.T.		
	JM01470	2 Bushing, R.H.T.		
	J-A-1252	2 Retainer		
	J-A-515	2 Seal, grease		
26	J-GM-120741	Bolt, hex. hd.	4	4
27	J-GM-120214	Lockwasher	4	4

REAR SPRING AND SHOCK ABSORBER




Fig. 71

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

REAR SPRING AND SHOCK ABSORBER

1	JM02183	Spring ass'y, rear	2	2
		Consists of :		
	JM02183-1	1 Leaf, rear spring No. 1		
	JM02183-2	1 Leaf, rear spring No. 2		
	JM02183-3	1 Leaf, rear spring No. 3		
	JM02183-4	1 Leaf, rear spring No. 4		
	JM02183-5	1 Leaf, rear spring No. 5		
	JM02183-6	1 Leaf, rear spring No. 6		
	JM02183-7	1 Leaf, rear spring No. 7		
	JM02183-8	1 Leaf, rear spring No. 8		
	JM02183-9	1 Leaf, rear spring No. 9		
	JM02183-10	1 Leaf, rear spring No.10		
	JM02183-11	1 Leaf, rear spring No.11		
	JM02183-12	1 Bushing, eye		
	JM02183-13	1 Nut, center bolt		
	JM02183-14	1 Bolt, center		
	JM02183-15	2 Clip, inner		
	JM02183-16	2 Clip, outer		
	JM02183-20	4 Rivet		
2	J-384228	Bolt, pivot	2	2
3	JM01155	Nut, hex.	2	2
4	J-GM-137185	Pin, cotter	2	2
5	JM03092	Fitting	6	6
6	M J-A-513	Bolt, "U" spring shackle L.H.T. (Left, rear)	1	1
7	M J-A-514	Bolt, "U" spring shackle R.H.T. (Right, rear)	1	1
8	JM01471	Bushing, spring shackle L.H.T.	1	1
9	JM01470	Bushing, spring shackle R.H.T.	3	3
10	J-A-1252	Retainer, grease seal	4	4
11	J-A-515	Seal, grease	4	4
12	J-640932	Plate and shaft L.H.	1	1

Key	Parts No.	Nomenclature
-----	-----------	--------------

REAR SPRING AND SHOCK ABSORBER (Continued)

13	J-640938	Plate and shaft R.H.T.	1	1
14	J-642987	Bolt, "U" spring	4	4
15	JM01154	Lockwasher	8	8
16	J-339372	Nut, clip to axle	8	8
17	J-637936	Bushing, mounting pin	8	8
18	JM02441	Absorber, shock, rear	2	2
	JM06647	Absorber, shock, rear	4	4
19	J-641916	Washer, mounting pin	4	4
20	J-GM-103407	Pin, cotter	2	2
21	JM02183-12	Bushing, eye	4	4
22	J-GM-120741	Bolt, hex. hd.	1	1
23	JM01473	Bushing, spring shackle L.H.T.	3	3
24	JM01472	Bushing, spring shackle R.H.T.	2	2
25	J-906826	Bumper, axle	4	4
26	J-GM-120214	Lockwasher	1	1
	J-802061	Kit, spring shackle "U" bolt L.H.T.	1	1
		Consists of :		
	J-A-513	1 Bolt, "U" L.H.T.		
	JM01471	1 Bushing, L.H.T.		
	JM01470	1 Bushing, R.H.T.		
	J-A-1252	2 Retainer		
	J-A-515	2 Seal, grease		
	J-802062	Kit, spring shackle "U" bolt R.H.T.	1	1
		Consists of :		
	J-A-514	1 Bolt, "U" R.H.T.		
	JM01470	2 Bushing, R.H.T.		
	J-A-1252	2 Retainer		
	J-A-515	2 Seal, Grease		

FENDER




Fig. 72

		No. Req'd	
Key	Parts No.	Nomenclature	J4 J4C
FENDER			
1	JM00453	Fender, front L.H.	1
	JM06365	Fender, front L.H.	1
	JM00457	Fender, front R.H.	1
	JM06366	Fender, front R.H.	1
2	J-663548	Catch, hood ass'y	2 2
3	J-GM-120854	Bolt, hex. hd.	4 4
4	J-GM-120386	Washer, plain	4 4
5	J-GM-120380	Lockwasher	4 4
6	J-GM-120375	Nut, hex.	4 4
7	JM00730	Brace, front fender L.H.	1 1
	J-A-2844	Brace, front fender R.H.	1 1
8	J-GM-446363	Washer, plain	6 6
9	J-673488	Screw and lockwasher	6 6
10	JM00832	Support, vinyl tube	1 1
11	J-GM-122007	Bolt, hex. hd.	6 6
12	JM00750	Lockwasher	8 8
13	J-GM-120229	Bolt, hex. hd.	2 2
14	J-A-2662	Anti-squeak, front fender lower	2 2
15	J-GM-138485	Lockwasher	2 2
16	J-GM-120376	Bolt, hex. hd.	2 2
17	J-A-3158	Anti-squeak, front fender upper	2 2
18	J-GM-120678	Bolt, hex. hd. L.H.	2 2
	J-GM-123814	Bolt, hex. hd. R.H.	2 2
19	J-GM-120382	Lockwasher	4 4
20	JM00819	Lockwasher	4 4

HOOD (J4)




Fig. 73

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HOOD (J4)

	JM00459	Hood ass'y, complete	1	
	JM00460	Hood ass'y	1	
1	JM03932	Hinge, hood	1	1
2	JM03932-3	Pin, hood hinge	1	1
3	J-663640	Bracket, hood catch	2	2
4	J-GM-191985	Screw and lockwasher	4	4
5	J-GM-120386	Washer, plain	4	4
6	J-GM-120375	Nut, hex.	4	4
7	J-GM-443874	Screw, hex. hd.	4	
8	J-GM-120385	Washer, plain	4	
9	J-GM-120217	Lockwasher	4	
10	J-GM-120361	Nut, hex.	4	
11	JM04562	Bumper ass'y, hood	2	
12	JM03775	Bumper, hood	2	
13	JM03776	Liner, hood bumper	2	
14	J-GM-113454	Rivet	8	
15	J-GM-120854	Bolt, hex. hd.	5	
16	J-GM-120380	Lockwasher	5	
17	J-GM-120392	Washer, plain	5	
18				

HOOD (J4C)




Fig. 74

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HOOD (J4C)

	JM06438	Hood ass'y, complete		1
1	JM06361	Hood ass'y		1
2	JM03932	Hinge, hood		1
3	JM03932-3	Pin, hood hinge	1	1
4	J-663640	Bracket, hood catch	2	2
5	J-GM-191985	Screw and Lockwasher	4	4
6	J-GM-120386	Washer, plain	4	4
7	J-GM-120375	Nut, hex.	4	6
8	JM06450	Bolt, "U"		1
9	J-GM-120380	Lockwasher		7
10	J-GM-120854	Bolt, hex. hd.		5
11	J-GM-120392	Washer, plain		5

HOLDING BAR AND GROMMET




Fig. 75

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

HOLDING BAR AND GROMMET

1	J-GM-161895	Screw, pan hd. tapping	8	8
2	J-649890	Retainer, cover, gear shift lever	1	1
3	J-664379	Cover, housing gear shift lever	1	1
4	J-663793	Ring, grommet transfer shift lever	1	1
5	J-666611	Grommet, gear shift transfer case	1	1
6	JM00676	Bar, holding ass'y	1	1
7	J-GM-427752	Bolt, hex. hd.	4	4
8	J-GM-120380	Washer, spring	4	4
9	JM01288	Plug.....		2

GLOVE COMPARTMENT LID




Fig. 76

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

GLOVE COMPARTMENT LID

1A	JM00577	Lid, glove compartment ass'y, complete	1	
	JM06600	Lid, glove compartment ass'y, complete		1
1B	JM00579	Lid, glove compartment	1	
	JM06601	Lid, glove compartment		1
2	JM00276	Key, glove compartment lid	1	1
3	J-GM-120211	Screw, rd. hd.	2	2
	J-GM-120221	Screw, rd. hd.		2
4	J-GM-120385	Washer, plain	4	4
5	J-GM-120217	Lockwasher	2	2
6	J-GM-120361	Nut, hex.	2	2
7	JM00284	Plate, glove compartment lid	1	1

DRIVER SEAT




Fig. 77

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
DRIVER SEAT				
	JM00761	Seat, driver ass'y	1	
	JM06328	Seat, driver ass'y		1
1	JM00762	Frame, driver seat ass'y	1	1
2	JM00767	Frame, driver seat ass'y lower	1	1
3	JM00771	Frame, driver seat ass'y upper	1	1
4	J-GM-120228	Bolt, hex. hd.	2	2
5	JM01286	Pan, driver seat ass'y	1	1
6	JM00764	Plate, driver seat	2	2
7	J-GM-120228	Bolt, hex. hd.	2	2
8	J-GM-120376	Nut, hex.	2	2
9	J-GM-120214	Lockwasher	2	2
10	JM00765	Plate, "U" driver seat	2	2
11	J-GM-120376	Nut, hex.	6	6
12	J-GM-120214	Lockwasher	6	6
13	J-GM-122045	Bolt, hex. hd.	4	4
14	JM02319	Cushion, front seat ass'y	1	
	JM06323	Cushion, front seat ssa'y		1
15	JM02319-1	Cover, front seat.....	1	
	JM06323-1	Cover. front seat.....		1
16	JM02320	Spring, cushion, seat	1	1
17	JM01524	Back, driver seat, ass'y	1	
	JM06329	Back. driver seat. ass'y		1
18	J-53732	Washer, plain	12	12
19	J-52990	Screw, oval hd.	12	12
20	JM01524-1	Cover, driver seat back	1	
	JM06329-1	Cover. driver seat back		1
21	JM01303	Spring, cushion, seat back	1	1
22	J-GM-120741	Bolt, hex. hd.	2	2
23	J-GM-120214	Lockwasher	2	2
24	JM00762-6	Pipe	4	4

PASSENGER SEAT ATTACHING PARTS (J4)




Fig. 78

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
PASSENGER SEAT ATTACHING PARTS (J4)				
1	JM00643	Pivot, front passenger seat hinge	2	2
2	J-GM-120229	Bolt, hex. hd.	4	4
3	J-GM-120376	Nut, hex.	4	4
4	J-GM-120214	Lockwasher	4	4
5	JM00743	Clip, frame front passenger seat	1	1
6	J-GM-159913	Screw, pan hd. crossrecess	2	2
7	J-GM-120361	Nut, hex.	2	2
8	J-GM-120217	Lockwasher	2	2
9	J-GM-120385	Lockwasher	2	2
10	JM04541	Bumper, front passenger seat	1	1
11	JM03641	Rubber pad	2	
12	J-GM-120376	Nut, hex.	4	6
13	J-GM-120214	Lockwasher	4	6
14	JM00990	Plate, rear seat frame	2	2
15	J-GM-120228	Bolt, hex. hd.	2	2
16	J-GM-120376	Nut, hex.	2	
17	J-GM-120214	Lockwasher	2	2
18	JM04193	Spring, lock, rear passenger seat	2	
19	J-GM-180073	Bolt, hex. hd.	4	4
20	JM04190	Guide bracket, rear passenger seat	1	
21	J-GM-120741	Bolt, hex. hd.	1	
22	J-GM-120368	Nut, hex.	1	
23	J-GM-178532	Lockwasher	3	
24	JM04189	Hook, rear passenger seat	1	
25	JM04179	Bolt, special	1	
26	J-GM-120361	Nut, hex.	1	
27	J-GM-138479	Lockwasher	1	

PASSENGER SEAT ATTACHING PARTS (J4C)





Fig. 79

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

PASSENGER SEAT ATTACHING PARTS (J4C)

1	JM00643	Pivot, front passenger seat hinge	2	2
2	J-GM-120229	Bolt, hex. hd.	4	4
3	J-GM-120376	Nut, hex.	4	4
4	J-GM-120214	Lockwasher	4	4
5	JM00743	Clip, frame front passenger seat	1	1
6	J-GM-159913	Screw, pan hd. crossrecess	2	2
7	J-GM-120361	Nut, hex.	2	2
8	J-GM-120217	Lockwasher	2	2
9	J-GM-120385	Lockwasher	2	2
10	JM04541	Bumper, front passenger seat	1	1
11	JM06525	Bumper		2
12	J-GM-120376	Nut, hex.	6	6
13	J-GM-120214	Lockwasher	6	6
14	JM00990	Plate, rear seat frame	2	2
15	J-GM-120228	Bolt, hex. hd.	2	2
16	JM04193	Spring, lock, rear passenger seat	2	2
17	J-GM-180073	Bolt, hex. hd.	4	4
18	JM6523	Hook, rear seat L.H.		1
19	JM06524	Hook, rear seat R.H.		1
20	JM06533	Bolt, special		2
21	J-GM-121801	Lockwasher		2

SAFETY BAND (J4)



Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

SAFETY BAND (J4)

1	JM00024	Band, safety, ass'y	2	
2	JM00026	Bolt, hex. hd.	2	
3	J-GM-120377	Nut, hex.	2	
4	J-GM-120381	Lockwasher	2	
5	JM00024-1	Band, safety	2	
6	JM00024-2	Hook, safety band	2	
7	JM00024-3	Spring, hook safety band	2	
8	JM00024-4	Ring, safety band	2	
9	JM00024-5	Plate, safety band	2	
10	JM00024-6	Fixture, end, safety band	2	
11	JM00024-7	Fixture, stop, safety band	2	
12	JM00024-8	Ring, cloth, safety band	2	
13	JM00024-9	Plate, safety band	2	

FRONT PASSENGER SEAT




Fig. 81

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FRONT PASSENGER SEAT				
	JM00749	Seat, front passenger ass'y	1	
	JM06322	Seat, front passenger ass'y		1
1	JM00694	Frame, front passenger seat and back	1	1
2	JM00925	Frame, front passenger seat	1	1
3	JM00928	Bracket, seat frame L.H.	1	1
4	JM00929	Bracket, seat frame R.H.	1	1
5	J-677836	Pin, front passenger seat	2	2
6	JM00930	Frame, front passenger seat back	1	1
7	JM00933	Bracket, seat back frame R.H.	1	1
8	JM00934	Bracket, seat back frame L.H.	1	1
9	J-52990	Screw, oval hd.	12	12
10	J-53732	Washer, plain	12	12
11	J-GM-120741	Bolt, hex. hd.	2	2
12	J-GM-116120	Lockwasher	2	
	J-GM-120214	Lockwasher		2
13	J-GM-104112	Rivet, rd. hd.	2	2
14	J-GM-120388	Washer, plain	4	4
15	JM02319	Cushion, front seat ass'y	1	
	JM06323	Cushion, front seat ass'y		1
16	JM02319-1	Cover, seat	1	
	JM06323-1	Cover, seat		1
17	JM02320	Spring, cushion, seat	1	1
18	JM01525	Back, front passenger seat ass'y	1	
	JM06324	Back, front passenger seat ass'y		1
19	JM01303	Spring, cushion, seat back	1	1
20	JM01525-1	Cover, front passenger seat back	1	
	JM06324-1	Cover, front passenger seat back		1
21	JM01286	Pan, front passenger seat ass'y	1	1

RIFLE HOLDER




Fig. 82

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C


RIFLE HOLDER

1	JM04319	Holder, rifle	1	1
2	J-GM-122096	Bolt, hex. hd.	2	2
3	J-GM-120382	Lockwasher	2	2
4	J-GM-120388	Washer, plain	1	1

PIONEER TOOL SUPPORT

1	JM04357	Clamp, axe front	1	
	JM06655	Clamp, axe front		1
2	J-GM-120214	Lockwasher	4	4
3	J-GM-120376	Nut, hex.	6	6
4	J-673769	Bracket, shovel cowl	1	1
5	JM00621	Loop, footman	3	3
6	J-673768	Strap ass'y, shovel front	1	1
7	J-GM-155937	Screw, fl. hd.	6	6
8	J-GM-116000	Nut, hex.	6	6
9	J-GM-115707	Lockwasher	6	6
10	JM00889	Strap ass'y, shovel rear	1	1
11	J-673767	Strap ass'y, axe	1	
	JM06657	Strap ass'y, axe		1
12	J-673645	Clamp, axe rear	1	1
13	J-GM-120697	Screw, pan hd.	4	4
14	J-GM-120375	Nut, hex.	4	4
15	J-GM-120380	Lockwasher	4	4
16	J-GM-133827	Screw, pan hd.	2	2
17	J-GM-155937	Screw, pan hd.	6	6
	J-GM-120391	Washer, plain	6	6

PIONEER TOOL SUPPORT



WINDSHIELD (J4)




Fig. 84

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
WINDSHIELD (J4)				
	JM04174	Windshield ass'y, complete	1	
1	JM04175	Windshield ass'y	1	
2	J-673551	Screw and lockwasher	4	4
3	JM04177	Retainer, windshield frame	1	
4	J-670953	Loop, spacer, support	1	1
5	J-681373	Retainer ass'y, L.H.	1	1
6	J-681369	Bracket, door hinge L.H.	1	1
7	J-681371	Retainer, L.H.	1	1
8	J-681374	Retainer ass'y, R.H.	1	1
9	J-681370	Bracket, door hinge R.H.	1	1
10	J-681372	Retainer, R.H.	1	1
11	JM03763	Bracket ass'y, mirror	1	1
12	JM03764	Bracket, mirror	1	1
13	J-GM-120706	Bolt, hex. hd.	2	
14	J-GM-145255	Screw, tapping	2	2
15	J-663677	Clamp ass'y, windshield	2	2
16	JM00005	Glass, windshield	2	2
17	J-670923	Weatherstrip, windshield glass	1	1
18	J-670924	Strip, filler	1	1
19	J-671045	Weatherstrip, windshield to cowl	1	
	JM05888	Weatherstrip, windshioild to cowl		1
20	J-GM-145193	Screw	17	17
21	JM00001	Retainer	1	1
22	J-GM-157070	Screw	4	4
23	JM00003	Retainer	1	1
24	JM00383	Weatherstrip, windshield	2	2
25	JM02122	Lid ass'y, windshield	1	1
26	JM02126	Handle ass'y, windshield	1	1
27	J-671198	Pin, windshield	1	1
28	J-671205	Spring, windshield	1	1

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

WINDSHIELD (J4) (Continued)

29	J-GM-160035	Screw	1	1
30	J-GM-120217	Lockwasher	3	3
31	J-GM-120385	Washer, plain	1	1
32	J-GM-160075	Screw	2	2
33	JM02128	Washer	2	2
34	J-GM-120614	Nut, hex.	2	2
35	J-GM-122017	Bolt, hex. hd.	4	4
36	J-GM-120393	Washer, plain	4	4
37	J-805002	Nut and lockwasher	4	
38	JM04517	Bolt, pivot windshield	2	2
39	J-A-2220	Lockwasher	2	2
40	J-668922	Washer, plain	2	2
41	J-681241	Bracket ass'y, pivot windshield L.H.	1	1
	J-681242	Bracket ass'y, pivot windshield R.H.	1	1
42	J-671015	Plate, tapping windshield	2	2
43	J-A-2939	Plate, tapping windshield clamp	2	2
44	J-A-3763	Catch, clamp windshield	2	2
45	J-GM-120697	Screw, rd. hd.	4	4

WINDSHIELD (J4C)

	JM06350	Windshield ass'y, complete	1	
1	JM06351	Windshield ass'y	1	
2	J-673551	Screw and lockwasher	4	4
3	JM06352	Retainer, windshield frame		1
4	J-670953	Loop, spacer, support	1	1
5	J-681373	Retainer ass'y, L.H.	1	1
6	J-681369	Bracket, door hinge L.H.	1	1
7	J-681371	Retainer, L.H.	1	1
8	J-681374	Retainer ass'y, R.H.	1	1
9	J-681370	Bracket, R.H.	1	1

WINDSHIELD (J4C)




Fig. 85

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
WINDSHIELD (J4C) (Continued)				
10	J-681372	Retainer, R.H.	1	1
11	JM03763	Bracket ass'y, mirror	1	1
12	JM03764	Bracket, mirror	1	1
13	J-GM-121867	Bolt, hex. hd.	2	2
14	J-GM-145255	Screw, tapping	2	2
15	J-663677	Clamp ass'y, windshield	2	2
16	JM00005	Glass, windshield	2	2
17	J-670923	Weatherstrip, windshield glass	1	1
18	J-670924	Strip, filler	1	1
19	J-671045	Weatherstrip, windsheild to cowl	1	1
20	J-GM-145193	Screw	17	17
21	JM00001	Retainer	1	1
22	J-GM-157070	Screw	4	4
23	JM00003	Retainer	1	1
24	JM00383	Weatherstrip, windshield	2	2
25	JM02122	Lid ass'y, windshield	1	1
26	JM02126	Handle ass'y, windshield	1	1
27	J-671198	Pin, windshield	1	1
28	J-671205	Spring, windshield	1	1
29	J-GM-160035	Screw	1	1
30	J-GM-120217	Lockwasher	3	3
	J-GM-120385	Washer, plain	1	1
	J-GM-160075	Screw	2	2
	JM02128	Washer	2	2
	J-120614	Nut, hex.	2	2
	J-2017	Bolt, hex. hd.	4	4
6		Washer, plain	4	4
7		Nut, hex.	4	4
8		Bolt, pivot windshield	2	2
9		Lockwasher	2	2

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
WINDSHIELD (J4C) (Continued)				
40	J-668920	Washer, plain	2	2
41	J-681241	Bracket ass'y, pivot windshield L.H.	1	1
	J-681242	Bracket ass'y, pivot windshield R.H.	1	1
42	J-671015	Plate, tapping windshield	2	2
43	J-A-2939	Plate, tapping windshield clamp	2	2
44	J-A-3763	Catch, clamp windshield	2	2
45	J-GM-120697	Screw, rd. hd.	4	4
46	J-GM-138485	Lockwasher	4	4
47	JM06435	Hood catch ass'y		1
48	J-GM-120854	Bolt, hex. hd.	2	2
49	J-GM-120392	Washer, plain	2	2
50	J-GM-120380	Lockwasher	2	2
51	JM06355	Bumper ass'y, L.H.		1
	JM06356	Bumper ass'y, R.H.		1
52	JM06140	Bumper L.H.		1
	JM06141	Bumper R.H.		1
53	JM03776	Liner, hood bumper		2
54	J-GM-113454	Rivet		8
55	J-GM-443874	Screw, hex. hd.		4
56	J-GM-120361	Nut, hex.		4

SPARE FUEL TANK SUPPORT




Fig. 86

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

SPARE FUEL TANK SUPPORT

1	JM04167	Support, fuel tank spare ass'y	1	1
2	J-GM-123780	Bolt, hex. hd.	4	4
3	J-GM-120368	Nut, hex.	4	4
4	J-GM-120214	Lockwasher	4	4
5	JM00162	Support, fuel tank spare	1	1
6	JM04169	Strap, spare fuel tank upper ass'y	1	1
7	JM04169-1	Strap, spare fuel tank	1	1
8	JM05358	Tip, strap spare fuel tank support	1	1
9	JM04170	Buckle, strap	1	1
10	JM04168	Strap, spare fuel tank	1	1
11	JM05469	Buckle, strap spare fuel tank	1	1
12	JM00264	Rivet	4	4
13	JM04167-4	Washer, plain	4	4
14	JM03707	Damper, spare fuel tank	2	2

SPARE WHEEL SUPPORT AND REAR BUMPER




Fig. 87

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J+C

SPARE WHEEL SUPPORT AND REAR BUMPER

1	JM04164	Bracket, spare wheel support upper ass'y	1	1
2	J-635516	Nut, hex. R.H.T. wheel hub bolt	3	3
3	J-GM-120640	Bolt, hex. hd.	2	2
4	J-GM-120677	Bolt, hex. hd.	2	2
5	J-GM-120369	Nut, hex.	12	12
6	J-GM-120381	Lockwasher	12	12
7	JM04165	Damper, spare wheel ass'y	1	1
8	J-GM-133056	Screw, rd. hd.	2	2
9	J-GM-120380	Lockwasher	2	2
10	J-GM-120386	Washer, plain	2	2
11	JM00028	Bumper, rear	2	2
12	J-GM-120758	Bolt, hex. hd.	8	8

REAR PASSENGER SEAT




Fig. 88

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
REAR PASSENGER SEAT				
1	JM04181	Seat, rear ass'y	1	
	JM06325	Seat, rear ass'y		1
2	JM04182	Frame, rear seat ass'y	1	
	JM06534	Frame, rear seat ass'y		1
3	JM04186	Stopper bracket, L.H.	1	
	JM06535	Stopper bracket, L.H.		1
4	JM04187	Stopper bracket, R.H.	1	
	JM06536	Stopper bracket, R.H.		1
5	JM04188	Stopper bracket, rear seat	1	1
6	J-GM-104112	Rivet, rd. hd.	2	2
7	J-GM-120388	Washer, plain	4	4
8	JM04183	Cushion, rear seat	1	1
9	JM04184	Back, rear seat	1	1
10	JM04185	Lock, cover rear seat	1	1
11	J-52990	Screw, pan hd.	46	46
12	J-53732	Washer, special	46	46

FOLDING TOP I




Fig. 89

Key	Parts No.	Nomenclature	No. Req'd J4	J4C
FOLDING TOP I				
	JM04265	Folding top, installation ass'y	1	
	JM06440	Folding top, installation ass'y		1
1	JM00886	Bow, top ass'y	1	1
2	JM00891	Bow, top front ass'y	1	1
3	JM00890	Bow, top rear ass'y	1	1
4	J-GM-104099	Rivet, rd. hd.	2	2
5	J-673804	Washer, special	2	2
6	J-GM-103321	Lockwasher	2	2
7	J-GM-120369	Nut, hex.	4	4
8	J-674790	Screw, thumb, chain and ring, top bow	2	2
9	J-672697	Strap, windshield hold down ass'y	2	
	J-668388	Strap, windshield hold down ass'y		2
10	JM00037	Bracket with nut, strap, top bow	2	2
11	J-GM-120741	Bolt, hex. hd.	6	
	J-GM-123473	Bolt, hex. hd.		6
12	J-GM-120214	Lockwasher	6	6
13	JM00621	Loop, footman	10	10
14	J-GM-155937	Screw, fl. hd.	20	20
15	J-GM-120361	Nut, hex.	20	20
16	J-GM-120217	Lockwasher	20	20
17	JM00881	Rod, side curtain, front ass'y	2	2
18	J-675205	Strap, stowage wheel house ass'y	4	4
19	JM04271	Rail, top ass'y L.H.	1	1
20	JM04272	Rail, top ass'y R.H.	1	1

FOLDING TOP II




Fig. 90

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
FOLDING TOP II				
1	JM00594	Strap ass'y, curtain	5	5
2	JM00610	Wind-seat	1	1
3	J-674925	Folding, door ass'y L.H.	1	1
4	J-GM-110949	Rivet, rd. hd.	2	2
5	J-GM-104083	Rivet, rd. hd.	4	4
6	JM00506	Wind-seat	2	2
7	JM00507	Zipper	1	1
8	J-674112	Handle, door	2	2
9	J-674113	Handle and Pin, door	2	2
10	J-674114	Plate, rub door handle	2	2
11	J-674926	Folding, door ass'y R.H.	1	1
12	JM00610	Wind-seat	2	2
13	JM00290	Plate, door handle	2	2
14	JM04266	Deck, top ass'y complete	1	
	JM06441	Deck, top ass'y complete		1
15	JM04283	Door, L.H. complete	1	
	JM06442	Door, L.H. complete		1
16	JM04284	Door, R.H. complete	1	
	JM06443	Door, R.H. complete		1
17	JM04285	Curtain, door ass'y L.H.	1	
	JM06446	Curtain, door ass'y L.H.		1
18	JM04286	Curtain, door ass'y R.H.	1	
	JM06447	Curtain, door ass'y R.H.		1
19	JM04267	Curtain, quarter ass'y L.H.	1	
	JM06444	Curtain, quarter ass'y L.H.		1
20	JM04268	Curtain, quarter ass'y R.H.	1	
	JM06445	Curtain, quarter ass'y R.H.		1
21	JM00594	Strap ass'y, curtain	6	6

FOLDING TOP III




Fig. 91

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

FOLDING TOP III

1	J-GM-120741	Bolt, hex. hd.	6	6
2	J-GM-120214	Lockwasher	6	6
3	JM00621	Loop, footman	11	
4	J-GM-120361	Nut, hex.	22	
5	J-GM-155937	Screw, fl. hd.	22	
6	J-GM-120217	Lockwasher	22	
7	J-681380	Retainer, door curtain cowl side	2	2
8	J-674105	Socket, door lower hinge ass'y L.H.	1	1
9	J-674106	Socket, door lower hinge ass'y R.H.	1	1
10	J-GM-145193	Screw, sheet metal	8	8
11	J-673771	Socket, with nut, top bow	2	2
12	JM00039	Bracket, with nut, top bow, front	2	2
13	J-GM-427926	Bolt, hex. hd.	4	4
14	J-GM-103321	Lockwasher	4	4
	J-GM-120377	Nut, hex.	2	2
	J-GM-122096	Bolt, hex. hd.	2	2

REAR VIEW MIRROR




Fig. 92

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C
REAR VIEW MIRROR				
	JM04230	Mirror, rear view ass'y (outside)	1	
	JM05910	Mirror, rear view ass'y (outside)		1
	JM04305	Mirror, rear view ass'y (inside)	1	1
1	JM01439	Mirror, rear view	3	3
2	JM00948	Spacer, rear view mirror	2	2
3	J-GM-120369	Nut, hex.	2	2
4	J-GM-120381	Lockwasher	2	2
5	JM00951	Washer, plain	2	2
6	JM00950	Bracket, rear view mirror	4	
	JM05912	Bracket, rear view mirror		4
7	J-GM-120677	Bolt, hex. hd.	1	1
8	JM04232	Arm, rear view mirror (outside)	2	
	JM05911	Arm, rear view mirror (outside)		2
9	JM04233	Clamp, pivot	2	2
10	J-GM-121615	Bolt, hex. hd.	2	2
11	J-GM-178551	Lockwasher	4	4
12	J-GM-160365	Screw	8	
	J-GM-132979	Screw		8
13	J-GM-121744	Lockwasher	8	8
14	J-GM-121743	Nut, hex.	8	8
15	JM02479	Arm, rear view mirror (inside)	1	1
16	J-GM-120380	Lockwasher	2	2
17	J-GM-120375	Nut, hex.	2	2

REFLECTOR




Fig. 93

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

REFLECTOR

1	JM02032	Reflector, red	2	
	JM06375	Reflector, red		2
2	J-GM-187865	Screw, rd. hd.	4	4
3	J-GM-120367	Nut, hex.	4	4
4	J-GM-120380	Lockwasher	4	4

WINDSHIELD WIPER (J4)

1	J-647412	Grommet	1	
2	JM00911-c	Hose (c)	1	
3	J-663369	Nut, windshield wiper	2	
4	J-667074	Connection, tee	1	
5	JM01253	Blade, windshield wiper	2	
6	JM01168	Tubing, windshield wiper	1	
7	J-671137	Arm, windshield wiper L.H.	1	
8	J-671138	Arm, windshield wiper R.H.	1	
9	J-671634	Clip, hose, windshield wiper	1	
10	J-680400	Screw and lockwasher	3	
11	J-GM-120361	Nut, hex.	3	
12	JM04198	Motor, windshield wiper	2	
13	JM03016	Hose, windshield wiper	1	
14	JM00911-b	Hose (b)	1	
15	JM00911-e	Hose (e)	1	
16	J-78316	Clip, wiper hose	4	2
17	J-GM-145193	Screw	1	
18	J-682123	Tubing, windshield wiper	1	
19	J-680787	Spacer, windshield wiper	4	
20	J-681277	Screw and lockwasher	4	2
21	JM04196	Hose, windshield wiper	1	
22	JM01254	Clip, wiper hose	1	1
23	J-GM-145193	Screw	1	

WINDSHIELD WIPER (J4)




Fig. 94

Key	Parts No.	Nomenclature	No. Req'd	
			J4	J4C

WINDSHIELD WIPER (J4) (Continued)

24	JM04197	Hose, windshield wiper	1	
25	JM03002	Clip, wiper hose	4	
26	J-GM-145193	Screw	1	
27	JM04195	Switch ass'y	1	
28	J-GM-160197	Screw	4	
29	J-GM-121743	Nut, hex.	2	
30	J-GM-125774	Lockwasher	2	
31	JM04217	Holder, hand wiper	4	
32	J-680400	Screw and lockwasher	2	
33	J-GM-120361	Nut, hex.	2	
34	J-GM-120391	Lockwasher	2	
35	JM01641	Blade, hand wiper	1	
36	JM04216	Arm, hand wiper	1	
37	JM01643	Clip	1	
38	J-GM-136042	Rivet	1	
39	JM01644	Washer, plain	1	
40	JM01645	Handle, hand wiper	1	
41	JM01648	Spacer, body	1	
42	JM01647	Spacer, bushing	1	
43	J-GM-121743	Nut, hex.	1	
44	J-GM-121744	Lockwasher	1	
45	JM01669	Washer, plain	1	
46	JM02192	Plug, windshield wiper	1	

WINDSHIELD WIPER (J4C)




Fig. 95

Key	Parts No.	Nomenclature	No. Req'd J4	Req'd J4C
WINDSHIELD WIPER (J4C)				
1	JM01225	Blade, windshield wiper		2
2	JM06389	Arm, windshield wiper		2
3	JM06374	Motor windshield wiper		2
4	J-681277	Screw & internal tooth lockwasher	4	2
5	J-GM-121801	Lockwasher, internal tooth		4
6	J-GM-120614	Nut, hex.		2
7	J-807311	Screw & internal tooth lockwasher		2
8	J-78316	Clip, wiper hose	4	2
9	J-GM-163600	Screw		3
10	J-GM-115707	Lockwasher		3
11	452S-65	Grommet		1
12	JM01254	Clip wiper hose		1

WINKER (J4)




Fig. 96

Key	Parts No.	Nomenclature	No. Req'd J4J4C
WINKER (J4)			
1	JM04212	Winker ass'y L.H.	1
2	JM04213	Winker ass'y R.H.	1
3	JM04224	Lamp, winker	2
4	JM04364	Nut, hex.	4
5	J-GM-121753	Washer, lock, external	4
6	JM04351	Window, winker	1
7	JM04352	Window, winker	1
8	JM04211	Handlever and harness	1
9	JM04222	Lamp, pilot, winker	1
10	JM00869	Connector, 4 wire	1
11	JM03925	Clip, harness	2
12	JM04214	Bracket, winker L.H.	1
13	JM04215	Bracket, winker R.H.	1
14	J-GM-120706	Bolt, hex. hd.	10
15	J-GM-120392	Washer, plain	10
16	J-GM-120380	Lockwasher	10
17	J-GM-120375	Nut, hex.	10
18	J-GM-192109	Clip	2
19	JM00396	Grommet, winker wire	2
20	J-78316	Clip, clamp, winker wire	2
21	J-GM-120361	Nut, hex.	2
22	J-GM-120217	Lockwasher	2
23	J-GM-120385	Washer, plain	2
24	J-GM-120211	Screw	2